

FIG. 1A

102620-886T0860

51




FIG. 1B

100a




FIG. 2A

FIG. 2B

102020-28610202




FIG. 3

FIG. 4




FIG. 4

FIG. 5

100




Fig. 5

600




Fig. 6

700




Fig. 7

00001003-020201

9:15 am

Address

RunMyTest

Calc

Data Book

HotSync

Memo Pad

Prefs

Security




SMS












To Do List

Welcome

Fig. 8b



 14mm
 


		
Address	Storage Test	Calc
		
Data Book	HotSync	Memo Pad
		
Prefs	Security	SMS
		
To Do List	Welcome	

830

855-

The screenshot shows the Sony Ericsson W660i home screen. At the top, the status bar displays '12:00' on the left, a battery level indicator in the center, and a signal strength indicator on the right. Below the status bar is a grid of application icons. The icons are arranged in three rows and three columns. The first row contains 'Address', 'Rumble Test', and 'Calc'. The second row contains 'Data Book', 'HotSync', and 'Memo Pad'. The third row contains 'Frets', 'Security', and 'SMS'. Below the grid, there are two more icons: 'To Do List' and 'Welcome'. The background is a dark, textured pattern.

850

[illegible]




Fig. 9

1000




Fig. 10